

FITTING INSTRUCTIONS

The Elite – With an elegant decorative gable at the front of the canopy this is a popular choice.

- Establish and mark on the wall, the centre line of door and desired height for the bottom of the soffit.
- Mark the centre line on the soffit of the canopy.
- Ensure the mounting surface is plumb and smooth.
- Mark out and pre-drill 3 to 9 holes (dependent on size of canopy) with 6mm holes along the back flange of the canopy.
- Offer canopy to wall, matching centre point of soffit to marked centre line on the door reveal. Check the canopy is level using spirit level.
- With the canopy held in position, mark centre points of fixing holes on wall through predrilled holes in the flange section of canopy.
- Remove canopy from wall.
- Drill 6mm diameter mounting holes in wall to required depth.
- Offer canopy to the wall, ensure centre lines match and place m8 wall bolts or 6 x 80 hammer fixing in drilled holes and then tighten.
- Silicone mastic on flange of canopy to the wall.
- If leg brackets are to be fit, in the centre of each end of the flat section on the bracket carefully mark and drill 6ml holes
- Offer the leg brackets to the desired position on each side of the canopy and mark hole position on the wall and soffit through pre drilled holes on the bracket.
- Remove the leg brackets and drill the marked positions on the wall only with 6ml drill bit
- Offer leg brackets to the wall and place plug and screw in drilled holes.
- Cover all visible screwheads with appropriate coloured screwcaps. You can also lead over the flange into the brickwork, completely optional.

Your overdoor canopy is maintenance - free, however we recommend regular cleaning with soap and water to maintain its's good looks for many years to come.

Care should be taken not to stand on the canopy as this may cause cracking or damage to the surface finish.







The Internet Shop Ltd trading as The Canopy Shop

t. 0345 2417182 f. 01536 446981 e. sales@thecanopyshop.co.uk www.thecanopyshop.co.uk