

Crescent Curved Roof Canopy

501x363x242cm / 16'5"Lx11'10³/₄"x7'11¹/₄"

 4mm 1/8" 10mm 3/8"						
 X2				7mm 5/16" 10mm 7/16" 13mm 9/16"		

IMPORTANT

Please read these instructions carefully before you start to assemble this canopy.
Please carry out the steps in the order set out in these instructions.
Keep these instructions in a safe place for future reference.

▷ Care and Safety advice

- Please follow the instructions as listed in this manual.
- Sort the parts and check against the list of contents.
- For safety purposes we strongly recommend that the product will be assembled by at least two people.
- Some parts have metal edges. Please be careful when handling components. Always wear gloves, shoes and safety goggles during assembly.
- Do not attempt to assemble the canopy in windy or wet conditions.
- Dispose of all plastic bags safely – keep them out of reach of small children.
- Keep children away from the assembly area.
- Do not attempt to assemble the canopy if you are tired, have taken drugs, medications or alcohol, or if you are prone to dizzy spells.
- When using a stepladder or power tools, ensure that you follow the manufacturer's safety advice.
- Do not climb or stand on the roof.
- Heavy articles should not be leaned against the poles.
- Do not hang or lay on part 216.
- If you are unsure if you require planning permission contact your local council.
- Keep roof and gutters clean of snow, dirt & leaves.
- Heavy amounts of snow on roof can damage the carport making it unsafe to stand below or nearby.
- This product was designed and produced for domestic use only.

▷ Some versions of this carport are painted.

If color was scratched during assembly it can be fixed with the following tints:

White – RAL 9016

Gray – RAL 7012

▷ Cleaning instructions

When your canopy needs cleaning, use a mild detergent solution and rinse with cold clean water.

Do not use acetone, abrasive cleaners, or others special detergents to clean the panel.

▷ Before starting assembly

- This carport must be assembled on a solid base (such as concrete or asphalt).
- Choose your site carefully before beginning assembly. Site surface (mainly below poles) needs to be level.
- During assembly use a soft platform below the parts to avoid scratches and damages.


▷ TOOL



▷ Notes (by steps)




Step 7: Screw 4000 intended to keep the parts (gable) stable till gutters will be assembled. If a third person can hold the parts till step 8, this screw can be assembled with all the others at step 33.




During assembly some screws are fastened fully by wrench while others are fastened just after the whole carport is assembled and leveled (step 21).
















Notice the marks on each step:




This carport should be assembled on a solid base (such as concrete). Without solid base, pre-foundation, that will include concrete and metal, is needed as in this drawing





Contents



Item	cm/Inc	Qty.	Item	cm/Inc	Qty.
		x6			x2
		x3			x2
		x3			x3
		x12			x2
		x4			x4
		x2			x14
		x2			x1
		x3			


Contents


Item	cm/Inc	Qty.
		
933		x6


		
934		x6


		
212		x12

		
4010	spare	x25 x1
		
4000	90mm / 3 ³ / ₄ " spare	x25 x1


		
424	M8 100mm / 4" spare	x25 x1


		
433	M8 spare	x100 x4


		
414	M8 spare	x39 x3

		
4038	M8 25mm / 1" spare	x13 x1


		
4040	M10 spare	x25 x1


		
4041	M10 spare	x13 x1


		
4039	M10 25mm / 1" spare	x13 x1


		
410	M6 spare	x4 x1


		
411	M6 spare	x44 x4


		
416	M6 spare	x114 x4


		
466	M6 spare	x159 x5


		
426	M8 spare	x13 x1


		
425	1/4 spare	x118 x4


		
1037		x2



		
1038		x2



		
1039		x2




		
1040		x4

		
450	32mm / 1 ¹ / ₄ " spare	x8 x1


		
54		x2

		
226		x4
		
225		x4

T001	7 ³ / ₄ / 20	x1
		
		
M6		

		
421	M4 16mm / 5/8" spare	x59 x3
		
427	M4 spare	x59 x3
		
422	M4 spare	x59 x3

1



213x6

933x6




934x6

212x12


414x24

433x48


424x24




x6



- 221L x2
- 221R x2
- 223 x2
- 1037 x2
- 1038 x2
- 416 x24
- 425 x24
- 466 x24





3




226 x4



225 x4



x2



416



x24

466






x24

425




x24



X2

x2



931 x3


936 x3

4039 x12


932 x3

4040 x24


4041 x12



x3




- 4038 x4
- 433 x8
- 414 x4








x1





- 433  x2
- 4010  x2
- 4000  x2





416



x12

466






x12


425



x12



X2



4038



x8

433







x16

414




x8





1035 x1



935 x1





416 x4









425 x4



466 x4









54








x2





- 416 x6
- 466 x6
- 425 x6
- 426 x4








1034 x2

935 x2


416 x8

425 x8

466 x8



x2



1033 x4


1040 x4

450 x4

416 x16


425 x16

466 x16





X2

x2







- 416 x8
- 410 x4
- 466 x12
- 425 x12
- 426 x8












411 x16

466 x16













1032










x12







x6














211






x14



x14











411



x4










466



x4





466







x8

411



x8





411









x8



466







x8






- 411  x4
- 466  x4








433  x22




4000  x22

4010  x22








- 421  x56
- 427  x56
- 422  x56



32 OPTION





t. 01536 446980 f. 01536 446981 e. sales@livingspaceltd.co.uk www.livingspaceltd.co.uk
Glazing Bars & Accessories • Canopies & Carports • Conservatory Roof Systems • Timber Glazing Systems